




Operating a Sony compatible Digital Media Player

1. Setting the audio mode

Put the stereo in the changer mode by pressing the SRC or MODE button.




2. Navigating the songs in a playlist

After the head unit is set to *CD Changer* mode, navigate the songs in a PhatNoise PhatBox playlist by using the *next/previous* track buttons.



3. Navigating the playlists in the PhatNoise PhatBox

To go from one playlist to another press the *next/previous* disc buttons.



4. Displaying information about your music

The name of a playlist can be shown by displaying the DISC title on your radio.
The name of a track can be shown by displaying the TRACK title on your radio.
Please consult your radio's user manual for assistance. Displaying information about your music is not automatic.