




Operating a TrafficPro compatible Digital Media Player

① Setting the stereo to CD Changer Mode


Put the head unit into CD changer mode by pressing the CD button

② Using the SSA/Voice Interface

The PhatBox uses the right hand knob to navigate through 6 "modes". Modes 2 through 5 are "browse" modes that allow you to browse all of the content on your DMS by playlist, artist, album, and genre. The 6th mode lists out features. The modes are in the following order:



Note: The CD Manager (not the Music Manager) creates one "playlist" for every CD copied onto the DMS cartridge. The "Discs" shown in the CD Manager software are referred to as "playlists" in the car.



③ Navigating Mode Items

After the car stereo is set to one of the 4 browse modes navigate through the list of items (playlists, artists, albums, or genres) by using the *next track/item* and *previous track/item* buttons.

④ Navigating Songs

After a few seconds of song play the PhatBox will automatically switch to Track Mode (1). Navigate through the tracks by using the *next track/item* and *previous track/item* buttons.